


# KLAMATH HALL SECOND FLOOR



IN CASE OF FIRE  
USE STAIRWAY FOR EXIT  
DO NOT USE ELEVATOR

FIRE ALARM SOUNDS  
LIKE A 3-PULSE  
TEMPORAL PATTERN

EMERGENCY  
PHONE NUMBER **911**

-  YOU ARE HERE
-  EXIT ROUTES
-  STAIRWAY
-  FIRE ALARM PULL
-  FIRE EXTINGUISHER
-  FIRE HOSE