



KLAMATH HALL THIRD FLOOR



← Third Floor – Odd Side →

Third Floor – Even Side

 IN CASE OF FIRE
USE STAIRWAY FOR EXIT
DO NOT USE ELEVATOR

FIRE ALARM SOUNDS
LIKE A 3-PULSE
TEMPORAL PATTERN

EMERGENCY
PHONE NUMBER **911**

-  YOU ARE HERE
-  EXIT ROUTES
-  STAIRWAY
-  FIRE ALARM PULL
-  FIRE EXTINGUISHER
-  FIRE HOSE